

ORBITAL TUBE SAW

OTS SERIE



ORBITALSERVICE®
THE FUTURE OF ORBITAL WELDING



Table of Contents

1. Safety instructions & declaration of conformity	3
2. Equipment instruction	5
3. Machine specification	8
4. Installation and operation	9
4.1 Take the machine out of the packing case and install it on the work table or the pipe stand purchased	9
4.2 Selection of cutting saw blade, according to the pipe wall thickness that will be cut	9
4.3 Installation and replacement of saw blade	10
4.4 Install the electric drive on the machine	10
4.5 Operation Procedure	11
4.5.1 Sawblade positioning	11
4.5.2 Clamp the pipe	12
4.5.3 Motor speed regulation	13
4.5.4 Pipe cut-off	14
4.5.5 Cleaning and maintenance	14
4.6 Cutting of tees and elbows	15
4.7 Tube Beveling Operation	16
5 Diagram of clamping jaws	17
6 Important notes	17
7 Tooling chart	18
8 Trouble shooting	19
9 Ordering information	20



1. Safety instructions & declaration of conformity

We take great pride in manufacturing safe, quality products. Please comply with the following safety rules and instructions before operating the equipment.



Read the following content before working

READ THE OPERATION MANUAL

Before installing, you should read the manual, and make sure you understand all setup and operating instructions, it can help you save time and avoid injuring the operator and the machines

INSPECT MACHINE & ACCESSORIES

Before starting the machine, look for loose bolts or nuts, leaking lubricant, and any other physical conditions that may affect operation. Properly maintaining the machine can greatly decrease the chances for injury.

ALWAYS READ SIGNS AND LABELS

Please read the marks and signs. All the marks and signs should be clear and easy to read, and you should carefully keep them.



Danger! Electric shock

Always disconnect machine to power source before moving or removing motor

Security of the electricity



Caution injure hand

Keep hands, arms and fingers clear of all moving parts



Wear Safety Goggle

Eye protection required. When using equipment, please wear safety goggles. No goggles, no work.



**ECDECLARATION OF CONFORMITY WITH
DIRECTIVE 2014/30/EU Electromagnetic Compatibility**

Date of Issue:	November 21st, 2024
Report No.:	20230278ER
Directive:	2014/30/EU
Conforming Machinery:	Orbital Tube Saw, OTS serie
Parameters:	Rated Voltage: 230V~ Rated Input: 1300W~1500W Rated Frequency: 50/60Hz
Manufacturer:	Orbitalservice GmbH Kreuzdelle 13, 63872 Heimbuchenthal, Germany
Harmonized Standards Referenced or Applied:	2014/30/EU EN IEC 55014-1:2021 EN IEC 55014-1:2021 EN IEC 61000-3-2:2019+A1:2021
We hereby certify that the machinery described above conforms with the essential health and safety requirements of council directive 2014/30/EU.	
Signed:	
Signatory:	Dirk Kunze CEO Orbitalservice GmbH



2. Equipment instruction

OTS Serie Orbital Tube Saw

We supply machines and equipment to diverse industries where process piping systems are essential to their operation but require divergent machine tool technology. From power and petrochemical to semiconductor, food and dairy, our wide range of portable tools can be found on all pipe and tube types, sizes and wall thicknesses.


The orbital pipe cutting machine is designed for cutting and beveling of thin-walled stainless steel, mainly used in food, pharmaceutical, semi-conductor, daily chemical and other fields. The cut end face is vertical without burrs and can be directly welded. The function of beveling can also be completed by using a bevel saw blade to ensure the welding quality when required.

Orbitalservice introduces the second generation technology to provide more options according to different applications. With a option of brushless motors 1300W and 1500W, the customized 1500W motor provides more powerful power and is suitable for the cutting of thicker wall pipes.

FEATURES:

- Compact design with light weight
- Cold cutting/beveling improve safety
- Vertical incision, burr-free end surface
- Multi-point clamping to avoid deformation
- Quick saw blade change
- Anti-winding cables are provided
- Second saw blade position to cutoff elbows or Tee





Description of major parts

Electric motor- Before order confirmation, Orbitalservice supply the OTSM1220 (1300W). The OTSM2220 (1500w) electric driven assembly as an option

Gear box- Supply the cutting force by gear reducer

Mounting plate- Provided to fix the machine on a table or tripod



Clamping handle- Clamp or release the pipe

Positioning hole- Fix the feed handle

Feed handle - Feed the cutting saw blade or beveling saw blade

Saw blade positioning knob - Tight or release it for saw blade location

Change direction pull pin - Pull up the pin, the machine rotation reversed.

Rotation handwheel- Rotate the machine, complete the cutting job.

Clamping pads - For small size tubes clamping

Clamping jaws - Hold the clamping pads; for larger size tubes clamping

Eccentric ring body - For positioning saw blade

1st saw position- Sawblade position for cutting straight tubes

2nd saw position- Sawblade position for cutting T or elbow

Packaging

The machine is delivered into a portable plywood case



For safety of transport, the machine is fastened to the wooden box bottom by two M12 screws.

Loosen the screws before removing the machine.

The motor assembly is individually stored in a plastic box.

Packing list:

OTS Cutting machine

Cutting saw blade - 3pcs

Tool set

Operation manual



3. Machine specification

Model	OTS3		OTS4		OTS6	
Pipe OD	6 - 80 mm		12 - 120 mm		16 - 171 mm	
	0.236 - 3.15 inch		0.472 - 4.724 inch		0.63 - 6.73 inch	
Wall thickness	≤ 5mm	≤ 8mm	≤ 5mm	≤ 8mm	≤ 5mm	≤ 8mm
	≤ 0.197 inch	≤ 0.315 inch	≤ 0.197 inch	≤ 0.315 inch	≤ 0.197 inch	≤ 0.315 inch
Motor	OTSM1220	OTSM2220	OTSM1220	OTSM2220	OTSM1220	OTSM2220
Power Supply	220-230V 1PH50/60HZ					
Motor Power	1300W	1500W	1300W	1500W	1300W	1500W
Saw Blade RPM	85-210	85-210	85-210	85-210	85-210	85-210
Clamping jaws	4					
Net Weight	31 kgs	32 kgs	40 kgs	41 kgs	55 kgs	56 kgs
Shipping Weight	44 kgs	45 kgs	53 kgs	54 kgs	70 kgs	71 kgs
Package	Plywood case					
Packing size	620*460*550mm		640*490*580mm		690*540*630mm	

Model	OTS8		OTS12	
Pipe OD	55 - 228 mm		140 - 330mm	
	2.165 - 8.976 inch		5.512 - 12.99 inch	
Wall thickness	≤ 5mm	≤ 8mm	≤ 5mm	≤ 8mm
	≤ 0.197 inch	≤ 0.315 inch	≤ 0.197 inch	≤ 0.315 inch
Motor	OTSM1220	OTSM2220	OTSM1220	OTSM2220
Power Supply	220-230V 1PH50/60HZ			
Motor Power	1300W	1500W	1300W	1500W
Saw Blade RPM	85-210	85-210	85-210	85-210
Clamping Jaws	6			
Net Weight	60 kgs	61 kgs	81 kgs	82 kgs
Shipping Weight	78 kgs	79 kgs	105 kgs	106 kgs
Package	Plywood case			
Packing size	750*600*690mm		850*700*780mm	



4. Installation and operation

4.1 Take the machine out of the packing case and install it on the work table or the tripod purchased.

1) When it is necessary to install on the desktop work table, drill two M10 holes on the desktop according to the mounting holes on the base plate of the machine. The machine is then secured to the table top using the two sets of M10 locking bolts delivered.



2) If you have purchased a stand, first assembly it, and then fix the machine directly on the stand, all the installation holes have been completed before delivery.

3) Or can use a C-shapeclamp fix the machine on the table.

4.2 Selection of cutting sawblade, according to the pipe wall thickness to be cut

Part No.	Spec.				Wall Thickness
	OD(mm)	Qty of Teeth	ID(mm)	Thk (mm)	mm
SB6364	63	64	16	1.6	1.0-2.5
SB63100	63	100	16	1.2	0.7-1.5
SB6844	68	44	16	1.8	2.0-7.0
SB6872	68	72	16	1.6	1.0-3.0
SB8034	80	34	16	2	5.0-12.0
SB8044	80	44	16	1.8	5.0-10.0
SB8054	80	54	16	1.8	2.0-7.0
SB8080	80	80	16	1.8	1.0-2.5

Remark: SB6872, SB6844, SB8080 and SB8054 are the most common used saw blades.




4.3 Installation and replacement of the saw blade

Loosen the saw blade lock nut using the wrench provided. Counter clockwise direction

Note:

1. Please pay attention to the teeth direction of the saw blade during installation (can be reconfirmed according to the sign before cutting)
2. Installation sequence : saw blade / spacer / lock nut
3. Please use the delivery brush to clean up the iron chips and keep clean



4.4 Install the electric drive on the machine

Clean the mounting contact surface with the delivery brush before installing the drive, fix the 2 screws, finish the installation of the electric drive.



Note: Everytime installation of the motor to the machine, the contact surface must be clean and free of chips.




4.5 Operation Procedure

4.5.1 Sawblade positioning



Put the pipe into the machine, pipe end 3-5mm away from the saw blade, and gently lock the Pipe

Lock : Rotate the clamping handle clockwise

Release : Rotate the clamping handle counterclockwise



Press the feed handle to the bottom, pull up the handle, and insert it into the positioning hole






Loosen the saw blade positioning knob. At this time, the eccentric ring body can rotate. Rotate the motor counterclockwise. When the saw blade crosses the inner wall of the pipe and exposes 2-3 teeth, lock the positioning knob. The saw blade positioning is completed.

Positioning Knob :

Release: Rotate the knob counterclockwise

Lock: Rotate the knob clockwise



4.5.2 Clamp the pipe


Lift the feed handle and keep the saw blade away from the pipe





Mark the cutting line on the pipe according to the length to be cut.

Rotate the clamping handle counterclockwise. When the cutting line and the saw blade are at the same position, rotate the clamping handle clockwise to lock the pipe.



4.5.3 Motor speed regulation

Select the corresponding motor speed according to the material

If wall thickness is less than 3mm, select the speed 3-4

If wall thickness is more than 3mm, select the speed 1-2

When cutting the duplex or inconel tube, select the speed 1-2 and use lubricant







4.5.4 Pipecut-off

Connect the power source and turn on the motor.

Press the feed handle clockwise downward to allow the saw blade to cut into the inner wall of the pipe. Pull the feed handle outward and insert it into the positioning hole (The operation like the tool positioning)



Turn the rotation hand wheel clockwise to make the motor rotate one turn counterclockwise to complete the pipe cut-off.



Note: When the pipe material is hard, slow down the cutting speed.
Better performance when cutting oil is used

4.5.5 Cleaning and maintenance

After the cutting process, use the supplied brush to clean the iron chips on the machine.

Note: Do not use an air gun to blow the iron pins, it will avoid a possible danger.

After the machine is used, cleaning and greasing maintenance work should be done on time to extend the service life of the machine.



4.6 Cutting of tees and elbows

1. Use a straight pipe (same size as the Tee or Elbow size) to confirm the position of the saw blade (see the previous instructions for saw blade positioning)
2. Remove the saw blade at the first saw blade position. Install it at the second saw blade position
3. Cut the tee and elbow as needed





4.7 Tube Beveling Operation

1. Remove the cutting saw blade and replace it with a beveling saw blade
2. Insert the pipe and clamp it, make sure the beveling saw blade can cover the pipe wall thickness
3. Lock the pipe and start beveling

Note: The beveling function is an auxiliary function of this equipment. If you need efficient beveling, you can contact us.






5 Diagram of clamping jaws

Model	OTS 3	OTS 4	OTS 6	OTS 8	OTS 12
No Clamping Pads	Ø 6-80	Ø 29-120	Ø 74-171	Ø 128-228	Ø 230-330
With Clamping Pads	N/A	Ø 12-99	Ø 16-116	Ø 55-155	Ø 140-239

6 Important notes

1. Before start the machine
Clean the saw blade
2. Clean the machine
Do not use an air gun to blow away iron chips, as will cause iron chips to enter the machine, affecting the machine's accuracy and cutting accuracy.
3. Replace the saw blade
Before installing the blade, make sure there is no iron filings at the blade installation location
4. Lubricating
Lubricate the machine every week.





7 Tooling chart



Cutting Saw Blade

Part No.	Spec.					Thk(mm)	Wall Thickness	
	OD(mm)	OD(inch)	Qty of Teeth	ID(mm)	ID(inch)		mm	Inch
SB6364	63	2.48	64	16	0.63	1.6	1.0-2.5	0.039-0.098
SB63100	63	2.48	100	16	0.63	1.2	0.7-1.5	0.0276-0.059
SB6844	68	2.68	44	16	0.63	1.8	2.0-7.0	0.079-0.276
SB6872	68	2.68	72	16	0.63	1.6	1.0-2.5	0.039-0.098
SB8034	80	3.15	34	16	0.63	2	5.0-12.0	0.197-0.47
SB8044	80	3.15	44	16	0.63	1.8	5.0-10.0	0.197-0.394
SB8054	80	3.15	54	16	0.63	1.8	2.0-7.0	0.079-0.276
SB8080	80	3.15	80	16	0.63	1.8	1.0-2.5	0.039-0.098

Beveling Saw Blade

Part No.	Beveling Angle
SBB30R	30°
SBB35R	35°
SBB37.5R	37.5°
SBB45R	45°



Note: The beveling function is an auxiliary function of this machine and may not be able to complete the bevel work with high requirements.



8 Trouble shooting

Trouble	Possible reason	Remedy
The blade is loose	The nut locking the blade is not tightened	Tighten the hexagonal nut with the special wrench provided
Cannot cut	The saw blade is installed reversed	The direction of the saw blade tooth tip should be the same as the marked direction
Clamping not smoothly	The guide rail or screw rod is not clean and has debris.	Clean the guide rail or screw
Motor does not work	The overload protection device is triggered and the red light is always on.	Shut down the machine and restart it after 15 minutes
	When the machine is turned on, the motor does not rotate and the red light flashes quickly	Turn off the switch, unplug the plug, press the switch several times, and then turn it on again.
	The motor makes abnormal noises, sparks loudly, and the red light flashes slowly	Replace the motor carbon brushes
	The power cord is broken or the anti-tangle mechanism is disconnected	Find the disconnected location and reconnect it
The cut surface of the pipe is not vertical	There are iron chips on the bottom when installing the saw blade	Clean the iron filings from the saw blade installation position

Note:

If a problem not listed in the chart, stop operation and contact us for additional instructions



9 Ordering information

ORDERING OR MORE INFORMATION

To place an order or get more detailed information:

Tel.: +49-(0)6092 822 94-0

E-Mail: info@orbitalservice.de

Internet: www.orbitalservice.de

ORDERING REPLACEMENT PARTS

Please refer to parts lists provided in manual. Advise us part number and description of replacement parts to help expedite order and ensure proper parts are being ordered.

Or take photo for replacement parts, send an email to us.

REPAIR INFORMATION

Please call OrbitalService GmbH prior to returning any equipment for repair. We will advise you of shipping and handling. Please enclose with machine to be repaired your name, address, phone number and a brief description of the problem or work to be done or estimated.

All repair work done at our plant will be estimated and the customer advised of cost and time required to complete repair.

POSTAL ADDRESS

ORBITALSERVICE GmbH

Kreuzdelle 13

63872 Heimbuchenthal

Germany

Tel.: +49-(0)6092 822 94-0

E-Mail: info@orbitalservice.de

Internet: www.orbitalservice.de